



SHOWER BASKET EASY LIFT

Installation Guideline

- Using a suitable drill bit, drill holes in the marked positions to a suitable depth. If drilling through tile, use a ceramic drill bit.
- Insert wall plugs level with the surface of the wall. If fitting to a tiled surface, wall plugs should be inserted below the tile surface to avoid cracking. NB. For plasterboard walls, specialist fixings should be purchased, available from any DIY or hardware store.

Care Instructions

- Do not use abrasives or solvents when cleaning this product.
- Do not wash any products with black coat finish in the dish washer. Wipe off all water spillages using a soft, damp cloth.